



RH NEW LOGIC

An RH chair is the perfect work tool, a chair that puts you in an optimal position all day, every day. A few simple adjustments is all it takes to make your RH chair fit your individual anatomy. RH chairs support an upright posture and active sitting, increasing your performance.

Ergonomics

Providing complete support in any working position, enabling you to always sit correctly and breathe properly.

- The seat has rounded front and waterfall edge to reduce pressure on thighs. The depth of the seat can be adjusted separately.
- Sculptured shape provides comfort, keeps the back upright and gives support in any position. The pronounced "Tvedt cushion" encourages movement, upright position and open posture.
- Separately adjustable backrest angle for support in any position. Defined support for the lower back and with inflatable lumbar pump as standard.
- Pictograms on all handles and levers make the chair easy to use, easy to understand. The controls can be accessed even when seated.
- Comfort layer as standard gives increased comfort feel.
- Frictional tilt mechanism follows your every movement, easily lockable in any chosen position. The tilt resistance is quickly adjustable from 40kg 150 kg in 7 turns.
- Armrests are optional and adjustable (height, width, depth and turnable) The optional neck rest can be adjusted in height and depth.
- Easily interchangable seat and back that can be clicked on and off.

Quality

• 10 year guarantee

Flokk is certified in accordance to:

- ISO 9001
- ISO 14001

RH New Logic is certified in accordance to:

- EN 1335-1-2-3 Class A
- Möbelfakta
- BS 5459-2
- ANSI/BIFMA X5.1
- NPR 1813

Environment

- Supports companies' environmental profile and credibility (CSR) -Cradle to cradle proof
- Easy to disassemble and no glue or harmful chemicals
- EPD(ISO14025)
- The Nordic Swan
- GREENGUARD

Design

Materials and surfaces communicating comfort and wellbeing through bodyfitting forms. Expressing human performance.

Fire classifications

Foams and standard fabrics are tested to BS/EN 1021–1&2 (cigarette & match). Foam and fabric according to BS-5852 ignition source 5 (crib 5) can be delivered on request. Please contact our customer service for further information.

Maintenance

Vacuum clean the chair with a furniture brush or wipe it with a clean cloth or sponge slightly dampened with lukewarm clean water. Do not remove any plastic parts or attempt to open the seating mechanism. Contact your Flokk dealer if the chair requires servicing or maintenance.

See flokk.com/rh for RH New Logic interactive user instruction guide.



RH NEW LOGIC



MEASUREMENTS	RH NEW LOGIC 200	RH NEW LOGIC 220
Seat depth with seat slide	380-480 mm	380-480 mm
Seat depth	475 mm	475 mm
Seat width	470 mm	470 mm
Seat height - standard gas stem	388-520 mm	388-520
Seat angle adjustment	+6.1°/-16.9°	+6.1°/-16.9°
Height of lumbar support above the seat	143-241 mm	133-231 mm
Backrest height	540 mm	630 mm
Backrest height adjustment (from seat)	575-675 mm	575-675 mm
Backrest width	430 mm	430 mm
Back angle adjustment	20.6°	20.6°
Height of armrest above seat	195-310 mm	195-310 mm
Distance between armrests	320-512 mm	320-512 mm
Diameter of base	670 mm	670 mm

OPTIONS

- Neck rest Fabric Neck rest Leather Armrest 8L upholstered top, standard black leather Armrest 8Lupholstered top, other colors leather Armrest 8L top in TPU Uniform upholstery back and seat Upholstered back shell Decorative stitching (only for standard model)
- Coat Hanger Base 5T Polished Castor for hard floors Castor lockable Coccyx seat XL seat Seat with Memory foam Q3 (available Q3 2019)

GAS STEMS

Gas steam 4T Black Gas steam B Black Gas steam A Black

For other options see the RH Price List.

The design and specifications of RH Chairs' products are developed on an ongoing basis and the above formulations should not be perceived as completely final.