Care Instructions swopper



fe in Motio

Cover materials

swopper CLASSIC/swopper WORK with microfibre cover

- Optimum care is ensured by using just water and pH neutral soapsuds. Stains containing oil and fat should be treated beforehand with ethyl alcohol.
- Rinse with clear water after each cleaning treatment. Never use chlorinated detergents.
- Only dampen the seat and never make it completely wet, otherwise the cushioning under the fabric might be damaged. Therefore use only very small amounts of water and detergent.
- Avoid marks by cleaning from the edge of the seat to the middle.

Warning: Benzine, acetone and the like might dissolve the foam material under the cover.

swopper AIR Climate/net structure seat cover

- You can remove most stains easily using lukewarm water if necessary with a little pH-neutral detergent. Always use a clean, white cotton cloth for this.
- Rinse with clear water after each cleaning treatment. Never use chlorinated detergents.
- Only dampen the seat and never make it completely wet, otherwise the cushioning under the fabric might be damaged. Therefore use only very small amounts of water and detergent.

Warning: Benzine, acetone and the like might dissolve the foam material under the cover.

swopper CARE/Stamskin cover

- Carefully clean the cover with a brush and lukewarm water. If necessary, use soapy water and then wipe with a cloth and clear water.
- Only dampen the seat and never make it completely wet, otherwise the cushioning under the fabric might be damaged. Therefore use only very small amounts of water and detergent.

Warning: Do not use leather care products, stain removers, solvents or disinfectants.

PREMIUM leather cover

- If soiled, wipe with a soft, damp cloth, then rub down with a clean cloth.
- Treat subsequently with leather care products as required.

swopper STANDARD/Softex cover

• Use a damp cloth, if necessary with a liquid cleaning agent consisting of 50% water and 50% alcohol.

Cleaning of the foot ring

Marks left by the soles of shoes on the foot ring are best removed using a soft India rubber or a cloth with a drop of benzine.

